



PlayStation 3 Slim Top Cover Replacement

Remove the top cover to access your PlayStation 3 Slim's internals.

Written By: Andrew Bookholt



INTRODUCTION

Use this guide to remove the plastic top cover.

TOOLS:

- [Metal Spudger](#) (1)
 - [Phillips #1 Screwdriver](#) (1)
 - [T8 Torx Security Bit Screwdriver](#) (1)
-

Step 1 — Top Cover



- Turn the PS3 over and lay it on its backside.
 - Carefully peel the warranty sticker up off the lower case to reveal a hidden screw cover.
- ★ To avoid activating the **VOID** that may come up, heat the sticker carefully to remove and replace it cleanly.

Step 2



- Use the flat end of a metal spudger to pry up the seven screw covers around the edge of the lower case.

Step 3



- Remove the seven 37 mm Phillips screws securing the top cover to the lower case.

Step 4



- Remove the four 13.3 mm T8 security Torx screws beneath the Blu-ray drive opening. (Some models may only have three screws)

Step 5



- Lift the top cover from its rear edge and rotate it toward the front of the PS3.
- Lift the top cover off the PS3.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 04:38:53 AM.